



EMS-PT50X & PT30X
All Weather Shield
Assembly Installation
Diagram

Two (2) screws included
in hardware kit.

#1 Phillips screwdriver
recommended for
installation.