

E0	Normal Operating Condition
E1	Reverse Polarity (hot and neutral wires reversed)
E2	Open Ground (no ground wire connection)
E3	Line 1 High Voltage (line voltage above 132V)
E4	Line 1 Low Voltage (line voltage below 104V)
E5*	Line 2 High Voltage (line voltage above 132V)
E6*	Line 2 Low Voltage (line voltage below 104V)
E7	Line Frequency High (line frequency above 69Hz)
E8	Line Frequency Low (line frequency below 51Hz)
E9	Data Link Down (call technical support (800)-307-6702)
E10	Replace Surge Protector Module

Note: PE is a previous error code that has been rectified. No action is required.

***Code only applies to 50A models**

PRI-5002 0718